



1. Press **ON** to begin.



4. Smartboard.  
Interactive software tools.



2. Select source:  
**PC**  
**LAPTOP** or  
**DOC CAM**



5. Press **OFF** button to  
turn off the system.



3. Display tools:  
**AV MUTE**  
**FREEZE**  
**AUTO IMAGE**  
Room **Volume** Control