

# Franco 108 Podium & Smart Board Instructions



1. Touch screen to begin.
2. Touch red **Power** button to turn on projectors. **Front Near, Front Far, & Side choices.** Power button will highlight to green when projector is on. **Source choices are: PC, Laptop, & Doc Cam for projectors.** Touch screen to select source. Source will be **highlighted** in blue. Then touch **projector needed to add selected source.**




3. An additional **Laptop** can be added by using the HDMI cable in top "cubby".



**Audio** volume controls, **Mic Mute**, & **Audio Source** can be controlled by touch. System **Shutdown** is next Date & time.



4. System Shutdown. Touch the **Shutdown** button to turn off system. Touch **Confirm** to shutdown system.



## Franco 108 Smart Boards

The smart boards are interactive. Interactive by touch or with Epson Smart Pens. **Touch** smart boards for access to **tool bars**.

*(More instructions on the back)*



Need assistance? • Call H.E.L.P. or Ext. 4357 • Please report all problems!




## 1. Franco 108 Smart Boards



*(Instructions continued from front)*

The smart boards are interactive. Interactive by touch or with Epson Smart Pens.

Touch smart boards for access to tool bars.



## 2. Touch tab for smart board PC Interactive or PC Free Annotation.



## 3. Tool Bar Selections. PC Interactive

- PC mode
- White/Black board
- Back / Forward
- Mouse
- Highlight Pen Solid
- Highlighter Transparent
- Pen Tool
- Eraser Tools:
- Pen & Board options

Pen Options

## 4. Tool Bar Selections. PC Free Annotation.

Smart board Background options: White/Black board Lined and Graph.

## 6. System Shutdown.

Touch the Shutdown button to turn off system.

Touch Confirm to shutdown system.



Highlighter Options

Highlight Pen Options

## 5. Lower Tool Bar Selections.

Save, Zoom, AV Mute, Pause, Volume, Stopwatch, Power, and Dock.

