



1. Touch Logo to begin on touch screen.



2. Room Mode Selection:
Presentation
Video Conference
Audio Conference
Audio Only



3. Presentation mode:
Source
PC Laptop HDMI
Laptop VGA Share-Link
Blu-Ray DOC Cam
Aux Video

Screen Control:
UP
Down



Audio Control:
Instructor Mic, Student Mic & Program
UP Down & Mute



Audio Conference Dialer:
Dialer Controls



4. Video Conference:
Broadcast & Receive Mode
Source
PC Laptop HDMI
Laptop VGA Share-Link
Blu-Ray DOC Cam
Aux Video Stop Sharing



Display Control:
Projector, Instructor Display, & Student Display
ON, Off & Mute

VTC Dialer:
Dialer Controls



Camera Select:
Camera 1 & Camera 2 operation and settings for Broadcast & Receive Mode.



Cameras are programmed for Broadcast and Receive Mode operation call for assistance when needed with camera issues.



5. System Off. System OFF button
Power Down or Cancel buttons.

