

### 1. Touch Logo to begin on touch screen.

*(Touch panel for single projector control and use with display control)*

Alternative Control panel controls both projectors & screens for projector display.

Press SYSTEM ON button to turn on Projectors.

### 2. Room Mode Selection:

Presentation Both Screens

Presentation Near Screen

Presentation Far Screen

Close

### 3. Presentation mode:

Select Display

Far & Near Display

Select Source

PC Laptop HDMI DOC Cam

### 4. Control panel:




Controls both screens for projector displays.

PC button Laptop button

DOC button

Video Mute button

Volume control knob



### 5. Room Controls:

Instructor Mic

Up Down & Mute

Room Volume

Up Down & Mute

Display Control

Room Mode

System Off

Back Camera Control

### 6. Camera Control:

*(Huddle Camera - for Zoom)*

Pan/Tilt:

Up, Down,

Left, Right,

& Home

Camera Zoom:

+: Zoom in

-: Zoom out

Camera Presets:

1: Podium

2: Left Board

3: Right Board

4: Front Table

Close

### 7. Display Control:

Display Power

Far Display & Near Display.

On, Off, & Mute

### 8. System Off: Power Down

Power Down button.

Cancel Button.

Control panel: System OFF button to turn off Projectors and raise screens.

*Please remember to turn off room system, exit all programs, and log out of PC.*