




1. Touch screen to begin

2. Room Monitors

Rear monitor:
PC View only



Front Left (Far monitor)
& Right (Near monitor)



3. Select room mode

Presentation
Video Conference
Audio Only




4. Presentation Mode

Left & Right Display source choices
PC, Laptop HDMI, & Doc Cam
(Selections are highlighted in light blue)
Instructor Mic, & Room Volume Control

****Room audio right display only with PC, Laptop HDMI sources, & Aux Audio**

***To exit Room Mode: Touch the Room Mode button**




5. Video Conference Mode

Broadcast Mode or Receive Mode
PC, Laptop HDMI, Doc Cam
& Aux Audio Choices

VTC button for VTC Dialer screen
Display Control for Display Power screen

(Selections are highlighted in light blue)

***To exit Room Mode: Touch the Room Mode button**




6. Display Power

Control Left, Right, & Instructor(Rear) monitors On, Off, & Mute

Close button to exit screen

(Selections are highlighted in light blue)



7. VTC Dialer

For video conference calls

Dialer screen, Keypad, Call, End Call, Phone Book, & Privacy

Close button to exit screen



8. System Off - Power Down

System Off button, Power Down button

