
Perkins 03 Podium Instructions



Touch screen logo to begin.



2. Select room mode: Projection with Audio Or Audio Only.



Main Volume control: Volume Up, Down, & Mute.

Projection with Audio mode controls & sources.



Laptop, Blu-ray. & Booth HDMI Projector. On, Off & Mute Volume Up. Down, & Mute. Power Down

Audio Only mode controls & sources.



Laptop, Blu-ray, & Booth HDMI Projector, On, Off & Mute Volume Up, Down, & Mute. **Power Down**

Audio Control controls & sources.



Podium Mic Wireless Mic 1 Wireless Mic 2 Program Main Volume Up, Down, & Mute. For projector use in Audio Only mode use controls for projector and use screen wall

> plate control for raising and lowering projector screen.



Power Down button

to turn off system.



00

Laptop



Blu-ray

Blu- ray controls close up.



Need assistance? ● Call H.E.L.P. or Ext. 4357 ● Please report all problems!