PERKINS

Lion's Den AV Instructions



*The Lion's Den: The room AV that is available for request: Podium, Windows laptop computer, and 2 wireless microphones.



Press logo to begin.

Pull down screen for projection and presentation needs.



4. Audio Control:

Wireless Mic 1
Wireless Mic 2
Front Mic Jack
Window Mic Jack
Up, Down & Mute.

Audio for connected HDMI Device.

HDMI Front HDMI Window Up, & Down.



2. Room Mode Selection:

Presentation Mode

Room projector turns on.

Audio Only Microphones

Room Audio Controls.



Window Wall HDMI/Mic Jack



Audio Only
Press Audio control to change Microphone Volume

Volume
Control

Audio
Control

Audio
Control

3. Audio Only:

Press <u>Audio Control</u>

for microphone and
audio volume control.



Please remember to turn off room system, exit all programs, and log out of PC.

5. System Off then Power Down or Cancel.



Need assistance? ■ Call H.E.L.P. or Ext. 4357 ■ Please report all problems!